Trigonox 27

tert-Butyl peroxydiethylacetate

Initiator for (co)polymerization of acrylates and methacrylates.

CAS number 2550-33-6

EINECS/ELINCS No. 219-850-0

TSCA status listed on inventory Molecular weight 188.3

Active oxygen content peroxide 8.50%

Applications

Polymerization of styreneTrigonox 27 can be applied as an initiator for the polymerization and copolymerization of styrene in the temperature range of 80-100°C. During polymerization the temperature is increased in steps. A comparison is made between thermally and Trigonox 27 initiated (0. 16 mmole/100 g styrene) polymerization of styrene in a mass process, applying a typical temperature scheme.

Half-life data

The reactivity of an organic peroxide is usually given by its half-life (t1/2) at various temperatures. For Trigonox 27 in chlorobenzene half-life at other temperatures can be calculated by using the equations and constants mentioned below:

0.1 hr at 113°C (235°F) 1 hr at 93°C (199°F) 10 hr at 75°C (167°F) Formula 1 kd = A-e-Ea/RT Formula 2 $t\frac{1}{2}$ = (ln2)/kd Ea 134.0 kJ/mole
10 hr at 75° C (167°F) Formula 1 kd = A·e-Ea/RT Formula 2 $t^{1/2}$ = (ln2)/kd
Formula 1 $kd = A \cdot e \cdot Ea/RT$ Formula 2 $t\frac{1}{2} = (\ln 2)/kd$
Formula 2 $t\frac{1}{2} = (\ln 2)/kd$
Ea 134.0 kJ/mole
A 2.45E+15 s-1
R 8.3142 J/mole·K
T (273.15+°C) K

Thermal stability

Organic peroxides are thermally unstable substances, which may undergo self-accelerating decomposition. The lowest temperature at which self-accelerating decomposition of a substance in the original packaging may occur is the Self-Accelerating Decomposition Temperature (SADT). The SADT is determined on the basis of the Heat Accumulation Storage Test

SADT	35°C (95°F)
Emergency temperature (T _e)	25°C (77°F)
Control temperature (Tc)	20°C (68°F)
Method	The Heat Accumulation Storage Test is a recognized test method for the determination of the SADT of organic peroxides (see Recommendations on the Transport of Dangerous Goods, Manual of Tests and Criteria - United Nations, New York and Geneva).

Storage

Due to the relatively unstable nature of organic peroxides a loss of quality can be detected over a period of time. To minimize the loss of quality, Nouryon recommends a maximum storage temperature (Ts max.) for each organic peroxide product.

Ts Max.	15°C (59°F) and
Ts Min.	-30°C (-22°F)
Note	When stored under these recommended storage conditions, Trigonox 27 will remain within the Nouryon specifications for a period of at least three months after delivery.

Packaging and transport

In North America Trigonox 27 is packed in returnable, five gallon polyethylene containers of 35 lb net weight. In other regions the standard packaging is a 30-liter HDPE can (Nourytainer) for 25 kg peroxide solution. Both packaging and transport meet the international regulations. For the availability of other packed quantities consult your Nouryon representative. Trigonox 27 is classified as Organic peroxide type C; liquid, temperature controlled, Division 5. 2; UN 3113; PG II.

Safety and handling

Keep containers tightly closed. Store and handle Trigonox 27 in a dry well-ventilated place away from sources of heat or ignition and direct sunlight. Never weigh out in the storage room. Avoid contact with reducing agents (e. g. amines), acids, alkalis and heavy metal compounds (e. g. accelerators, driers and metal soaps). Please refer to the Safety Data Sheet (SDS) for further information on the safe storage, use and handling of Trigonox 27. This information should be thoroughly reviewed prior to acceptance of this product. The SDS is available at https://polymerchemistry.nouryon.com.

Major decomposition products

Carbon dioxide, 3,4-Diethylhexane, Pentane, tert-Butanol, 2-Pentene,

All information concerning this product and/or suggestions for handling and use contained herein are offered in good faith and are believed to be reliable. Nouryon, however, makes no warranty as to accuracy and/or sufficiency of such information and/or suggestions, as to the product's merchantability or fitness for any particular purpose, or that any suggested use will not infringe any patent. Nouryon does not accept any liability whatsoever arising out of the use of or reliance on this information, or out of the use or the performance of the product. Nothing contained herein shall be construed as granting or extending any license under any patent. Customer must determine for himself, by preliminary tests or otherwise, the suitability of this product for his purposes. The information contained herein supersedes all previously issued information on the subject matter covered. The customer may forward, distribute, and/or photocopy this document only if unaltered and complete, including all of its headers and footers, and should refrain from any unauthorized use. Don't copy this document to a website.

Trigonox, and Nourytainer are registered trademarks of Nouryon Chemicals B. V. or affiliates in one or more territories

Contact Us

Europe, Middle East, India and Africa polymerchemistry.nl@nouryon.com

Asia Pacific

polymerchemistry.ap@nouryon.com

Americas

polymerchemistry.na@nouryon.com

